



TinyGate

USB Digimode Interface

Instructions for Assembly
and user's manual

(Last change: 20/12/2020)

RF↔SYSTEM

TinyGate - User's manual and assembly instructions

Copyright

The contents of this document (of a merely exemplary function and thus non-exhaustive: documents, texts, images, audio and video data, logos, brands, all hereafter referred to as "Contents") are the exclusive property of the RF-SYSTEM and thus protected by the current legislation regarding copyright protection.

All rights reserved.

The reproduction and / or diffusion, even partial, by some analog and/or digital means, without the written consent of the copyright holder is forbidden. As a result, any unauthorised use of the "content" below is the full and exclusive responsibility of the users who respond themselves, according to the laws and regulations in force. The electronic copy of this manual is exclusively authorised for personal and study use, without any commercial aim, on written request. The aforementioned RF-SYSTEM reserves the right to make modifications and/or improvements to the assembly box at any time, without updating this manual

Copyright 2016 RF-SYSTEM ©
<http://www.rfsystem.it>

TinyGate - User's manual and assembly instructions

Table of contents

<u>Introduction.....</u>	<u>5</u>
<u>Warnings.....</u>	<u>6</u>
<u>Disclaimer.....</u>	<u>6</u>
<u>Technical characteristics.....</u>	<u>8</u>
<u>Technical specifications.....</u>	<u>10</u>
<u>Before beginning.....</u>	<u>12</u>
<u>Soldering advice.....</u>	<u>13</u>
<u>Preparation and setup.....</u>	<u>14</u>
<u>Assembly.....</u>	<u>15</u>
<u>Circuit board.....</u>	<u>15</u>
<u>Enclosure kit - Box.....</u>	<u>21</u>
<u>Connection cable for the transceiver.....</u>	<u>23</u>
<u>The transceiver cable.....</u>	<u>26</u>
<u>Examples of connection with transceivers.....</u>	<u>28</u>
<u>Elekraft KX3.....</u>	<u>29</u>
<u>Icom IC275, IC725, IC726, IC728, IC729, IC735, IC736, IC737, IC738, IC746PRO, IC756PROIII, IC761, IC765, IC775, IC781, IC820, IC821, IC910, IC970, IC7400, IC7600, IC7700, IC7800.....</u>	<u>30</u>
<u>Yaesu FT100D, FT817, FT857, FT897.....</u>	<u>32</u>
<u>We suggest to use the internal USB supply for the CAT interface to avoid to get the “+13,8V” from the CAT/LINEAR socket as external supply:.....</u>	<u>33</u>
<u>Yaesu FT1000 MARK-V, FT1000, FT990.....</u>	<u>34</u>
<u>Yaesu FT840.....</u>	<u>36</u>
<u>Yaesu FT2000, FT920.....</u>	<u>38</u>
<u>Yaesu FT450, FT950, FT991.....</u>	<u>39</u>
<u>Icom IC2720H, IC2725E.....</u>	<u>39</u>
<u>Kenwood TS480, TM255, TM455, TM-G707, TM-V7, TM-D700x.....</u>	<u>39</u>
<u>Kenwood TS140, TS440(S), TS450S, TS570, TS590, TS680, TS690, TS850, TS870S, TS940(S), TS950S, TS990, TS2000(X).....</u>	<u>40</u>
<u>Kenwood R1000.....</u>	<u>41</u>
<u>Kenwood TS50S.....</u>	<u>42</u>
<u>Icom IC703, IC706, IC718, IC7000, IC7100, IC7200, IC7300, IC7410, IC9100.....</u>	<u>43</u>
<u>CAT / CI-V interface.....</u>	<u>44</u>
<u>CAT/CI-V connections.....</u>	<u>44</u>


TinyGate - User's manual and assembly instructions

<u>CAT for ELECRAFT-Transceivers.....</u>	<u>47</u>
<u>CAT / CI-V power supply.....</u>	<u>48</u>
<u>PTT / CW / FSK outputs.....</u>	<u>50</u>
<u>SQL (COR) Input.....</u>	<u>53</u>
<u>Test – Initial operation.....</u>	<u>56</u>
<u>Windows XP.....</u>	<u>57</u>
<u>Windows 7.....</u>	<u>59</u>
<u>Windows 10.....</u>	<u>61</u>
<u>Linux - Ubuntu.....</u>	<u>63</u>
<u>MacOS -X.....</u>	<u>66</u>
<u>Examples of configurations for digital modes applications.....</u>	<u>69</u>
<u>Ham Radio Deluxe V 5.24- Digital Master 780.....</u>	<u>73</u>
<u>WSJT-X.....</u>	<u>80</u>
<u>FLDIGI & MacOS.....</u>	<u>81</u>

Introduction

The TinyGate Interface was created by Martin, IW3AUT and it's a compact USB interface for transceivers, which allows operation in digital modes via PC such as for example: PSK31, RTTY, WSPR, SSTV, EchoLink, APRS, Pactor, ROS as well as many others.

As a **3-in-1 interface** it makes available via a USB port a **sound card interface, a CAT / CI-V interface and a PTT / SQL / CW / FSK** with a galvanic isolation between the transceiver and the PC with transformers and optocouplers. The **TinyGate Interface** can be used with a wide variety of software applications for digital modes, which are available as freeware, shareware or as commercial products. As a result, this provides the amateur radio operator with easy and manageable access to the world of digital modes, thanks to the wide flexibility of adaptation of this interface to almost any transceiver.



Warnings

Disclaimer

This assembly box is made exclusively for radioamateur and educational-experimental use. As a result, it should be assembled and used by an expert with experience in the assembly of electronic circuits.

We do not accept any responsibility for bodily or material damage caused by the construction and use of this assembly box. As a result, assemble and use this kit at your own risk.

The operation may not be guaranteed, and even less so its eligibility for use of certain applications. The user should verify its applicability for their own applications and is responsible for the latter.

Errors of access and use are factors that are beyond our control, we are therefore not responsible for bodily or material harm caused by these errors or inexperience.

The guarantee applies exclusively to the individual parts (on the condition that these are assembled correctly) and not to the assembled product. The aforementioned RF-SYSTEM reserves the right to make modifications and/or improvements to the assembly box at any time, without updating this manual.

The two kits, once assembled, may not be resold if the necessary legal authorisations have not been previously requested and obtained.



Before using with a transceiver or receiver, the bridges on the JP1 socket must be configured correctly.

Incorrect configuration of these bridges may cause damage to the TinyGate and/or to the connected transceiver or receiver.

- It is advised that the parts are kept out of reach of children and away from pets, as they are a choking hazard.
- Do not inhale the fumes from the welding. Use a filter or device to remove these from the work station.
- Aerate the room after the welding activity.

TinyGate - User's manual and assembly instructions

- When using a soldering iron, place it down only once the rod has cooled down properly.
- Do not solder on live circuits.
- Carefully follow the instructions provided in this manual.
- In case of any doubt concerning the procedures to be followed, seek technical assistance.
- Do not try to modify the parts of the circuit that have already been assembled.

Technical characteristics

- **3-in-1 USB interface, just only one USB cable to your PC: built-in USB 2.0 High speed Hub**

- **Full galvanic isolation** between radio and USB interface

- **Integrated USB sound device:**

The power supply from the USB host is filtered additionally to keep a low noise on the A/D and D/A converters

Supported by the following operating systems: Windows XP, Windows 7, Windows 8, Windows 10, Macintosh OS X and LINUX.

Compliant with USB Audio Device Class Specification v1.0, there are no custom device drivers necessary.

- Provides 2 independant integrated USB COM-Ports:

1) CAT/CI-V serial interface:

Support for following radio control ports: CI-V, FIF-232, IF-232 (RXD+TXD)

Supported by the following operating systems: Windows XP, Windows 7, Windows 8, Windows 10, Macintosh OS X and LINUX.

2) PTT/SQL/CW/FSK interface:

Squelch(COR) input, positive or negative logic (for Echolink and remote control applications)

PTT relay output: direct keying control without VOX circuit

CW/FSK solid state output (can also be used as PTT: The smart jumper system allow to use either a relay or a solid state output as PTT)

Supported by the following operating systems: Windows XP, Windows 7, Windows 8, Windows 10, Macintosh OS X and LINUX.

- Controls for receiver and transmitter audio level
- Quick change USB and Radio interface connectors
- RJ45 connector for transceiver connection with a flexible pin selection jumper socket (attached to MIC connector, accessory or data port works with virtually all transceiver). A detachable radio cable can be made easily with a standard unterminated [RJ45-FTP network patch cable](#) (get a

Technical specifications

- USB 2.0 High speed interface
- USB Power requirements: 5V, max. 120mA
- Board size: 65x80mm
- USB sound interface (codec):

Chip: CMedia CM108AH

48 / 44.1kHz Sampling Rate for Both Playback (D/A) and Recording (A/D)

88 dB (typical) dynamic range

16-Bit DAC Output and 16-Bit ADC Input with a 22dB Microphone Boost
Audio Output:

Level 3Vpp max. @1k Ω typical (AC-coupled)

Frequency response (1 dB bandwidth): 0,02 – 11,5 kHz typical ([D/A frequency response](#) conditions: measured with a E-MU0202, include isolation transformer)

Second harmonic: -70 dB typical

Total harmonic distortion (THD): 0.06% typical

D/A Sampling rates: 44.1, 48 kS/s

Audio Input:

Input impedance: 600 Ω , (AC-coupled)

max. input level: 3Vpp, (Microphone Boost=OFF)

max. input level: 220mVpp, (Microphone Boost=ON)

Frequency response (1 dB bandwidth): 0,02 – 15 kHz typical ([A/D frequency response](#) conditions: measured with a E-MU0202, include isolation transformer)

[Noise floor screen capture](#) (span: 0 to 5kHz, 48 kHz Sampling Rate, disconnected input, [microphone Boost=OFF](#))

[Noise floor screen capture](#) (span: 0 to 5kHz, 48 kHz Sampling Rate, disconnected input, [microphone Boost=ON](#))

Dynamic Range: 88 dB typical

A/D sampling rates: 44.1, 48 kS/s

Audio transformers crosstalk attenuation: 60dB

TinyGate - User's manual and assembly instructions

- USB COM-Ports:
- Chip: FTDI FT232RL
Multi-Standard: CAT, FIF-232 (5V TTL), IF-232 (5V TTL), Inverted (for Elecraft, only for TinyGate board revision B). Max. guaranteed serial baudrate: 19200 baud
Interface power:
external powered from the transceiver / internal powered from the USB (internal powered works only without galvanic isolation)
PTT output: reed relay driven from RTS, max. 100V/0,5A
CW/FSK output: optoisolated open collector driven from DTR or TXD, max. 50V/50mA
Squelch input: optoisolated logic high or low to activate CTS, 4-20VDC
- Radio connector (RJ45):
Available signals: RX Audio, TX Audio (MIC), PTT, CW/FSK, COR, CAT/Logic Supply 8-15VDC

Before beginning

The assembly procedure of the TinyGate may be facilitated by certain small steps:

- Organise the work space for the procedure.
- Preferably use a wooden table with a sheet of antistatic map placed on top to prevent any parts that may fall from bouncing to the ground.
- Keep the necessary tools within arm's reach.
- Use a soldering iron whose tip is in good condition. Eventually change it as a preventative measure.
- Use a free solder alloy for electronics possibly without lead.
- Preferably use a rigorously earthed antistatic bracelet connected to through a resistor of 1 MegaOhm.
- Rushing is bad practice! Proceed with the most calm approach possible!!!

Soldering advice

For the assembly of the kit, no particularly sophisticated soldering equipment is necessary. Even with a good pen soldering tool (at least 30 watts of power) you can obtain optimum results. The key point for successful soldering is certainly the state of the tip. Damaged tips or tips which have lost the silver surface layer should be replaced. The tip, once heated, may be effectively cleaned by melting a small amount of solder alloy on it and then passing it repeatedly on a damp sponge (not soaking). The operation of cleaning with the sponge should be repeated regularly, in order to eliminate residues of fluxing and oxidising agents that may build up on it.

Preferably use lead-free solder alloys, even if the soldering in this case will not have a very shiny appearance and may as a result be more difficult to complete. The diameter of the alloy to be used simply depends on habit. Taking into account the "step" of the parts to be soldered, a soldering alloy with maximum diameter of 1mm should be entirely sufficient. Larger diameters may be difficult to manage, and smaller diameters may require more wire feeding during the fusion operations. One should not use fluxing agents or soldering pastes since modern soldering irons have a core that, upon melting, carries out the same function as the soldering paste.

Soldering operations should be carried out in a fast and decisive manner. Certain components (such as crystal) do not increase in size such that their leading wires must be insisted upon with the soldering iron. The same is true of the transformers. The soldering alloy should never be liquefied on the tip of the soldering iron, but on the leading wire of the part that is being soldered, following the heating of the same. After the fusion has begun it is necessary to apply the heat for several moments (1 or 2 seconds) so as to complete the fusion of the deoxidising agent and to guarantee optimal electrical contact. Do not exaggerate the quantity of tin that is melted on the leading wires, excesses tin may result in aesthetically awkward soldering or in short-circuits with the adjacent feet.

Once the soldering phase is complete, one should never blow on the soldering alloy. The cooling should take place slowly by convection.

Particular attention should be paid to the airtightness of the ground planes. In this case the large metallic surface has an elevated thermal capacity, and it may therefore be difficult (especially if the soldering iron is not overly powerful) to produce good soldering results.

TinyGate - User's manual and assembly instructions

Also in this case it is only a question of time, keeping the tip on the ground plane for a few seconds, such as to lightly heat it and then proceed to the use of the soldering alloy.

If an error is made, the excess tin may be removed with a desoldering braid (make sure it does not touch your fingers too much) or with tin remover (electrical or pump). The parts should be removed only when the soldering alloy has been correctly removed and without exerting too much force in the extraction. If the component is “stuck”, remove the tin more efficiently. Applying force with pliers or wire cutters may lead to insoluble damage to the printed circuit.

Preparation and setup

The pack containing the TinyGate kit has finally arrived, so, remembering what was said in the first section, the necessity is for a space that allows us to work comfortably and calmly.

Assembly


Circuit board

Once the preparations are complete, you may proceed with the assembly of the small parts remaining to be soldered. The parts represented in the following figures may be slightly different from those present in the kit.


Once the components have been identified it is necessary to proceed to the localisation of their assembly position. The operation is considerably simplified by the presence of the white silk screen printing on the printed circuit. For this one may also make reference to the assembly scheme at the end of the table that follows. Pay particular attention to the precise parallel alignment of the connectors and potentiometers with the edge of the board.

TinyGate - User's manual and assembly instructions


List of the parts to be soldered

<i>Pos.</i>	<i>Description</i>		<i>Desc.</i>
To	USB connector		X4
B	Jack stereo 3.5mm		X3
C	RCA connector (insert the part completely until the 6 white plugs are inserted entirely in the printed circuit)		X1
D	RJ45 socket with LED		X2
E	16 pin jumper socket		JP1
F	Reed Relays (The orientation of this component does not matter because of the symmetrical pinout) (SIP-1A05 or MS05-1A87-75LHR)		K1

TinyGate - User's manual and assembly instructions

G	<p>Dual LED (Red/Green) This led block should be aligned with the edge of the printed circuit.</p> 	DZ1
H / I	<p>Potentiometers 10kOhm with dial knobs</p> 	R2 / R3


TinyGate - User's manual and assembly instructions



TinyGate - User's manual and assembly instructions


For the relay (F) there are present overall in the printed circuit 7 holes with associated soldering pads. Nonetheless, the relay has only four pins: this is because the board is prepared for two different relays with different pinout pitch. If you find in the kit a relay type SIP-1A05, it should be connected in **three round holes and in one oval**. For the relays of type MEDER MS05-1A87-75LHR are supposed to use **4 oval-shaped pads**. The orientation of the relay is immaterial because of the symmetrical pin assignment. In all of these cases, the position and the distance between the holes make it almost impossible to connect the relay incorrectly.

Relay pinout details:



TinyGate - User's manual and assembly instructions

View of the full assembled board:




Enclosure kit - Box



There is also available an enclosure kit for the TinyGate, cut to fit the TinyGate board and two panels which are already perforated.

The two panels (front and back panel) are thus ready to be completed by applying the two polyester self-adhesive labels.



TinyGate - User's manual and assembly instructions

The two masks have been cut with precision and for this reason they should be aligned with the centre of the holes present on the two covers. For this, we recommend you try the alignment first without taking off the protective film, because the adhesive on these masks is very strong, and so it is difficult to re-position the masks once they have been attached.



CAUTION:

Before assembling the board in the enclosure the jumpers must be inserted on JP1, which define the assignment of the pins with the RJ45 X2 socket: see [*Assignment of pin for the transceiver cable*](#)

The assembly of the board in the enclosure is very easy: it is sufficient to insert it in the aluminium edging, using the second base guide as a seat for the board. The board is slightly longer than the aluminium box, but this is necessary to allow you to block in a stable way once fixed the two panels with the respective self-threading screws supplied with the enclosure.

After the assembly of the covers the two dial knobs may be applied for the two "TX" and "RX" potentiometers on the front panel. Before inserting the dial knob in the shaft it is necessary to ensure that both the potentiometers are turned anticlockwise, the position corresponding to the first white mark present on the adhesive label. Right on this mark the dial knob that is going to be inserted in the shaft should also be aligned. The dials should be lined up manually (at approx. within 2-3mm of the mask) but without using equipment such as a hammer or similar tools.

Connection cable for the transceiver

TinyGate allows you to freely define the assignment of the pins on the RJ45 X2 connector. The transceiver is connected to this connector via a patch cable that is supplied in the kit, to which may be assigned the following signals available on the JP1 socket:

<i>Signals</i>	<i>Description</i>
SPK	<p>Input for the audio signal reception coming from the demodulator (AC-coupled)</p> <p>This signal, according to the transceiver model, may be available on the microphone socket, DATA, the ACCessory socket or else on a jack. You can find indications in the manual of your transceiver if and where an audio output is available.</p> <p> Advice: Not all transceivers have all of the necessary signals (SPK, MIC et PTT) available on a single connector. The RCA X1 (CW / FSK) socket may be for example also used as an audio input (or else as any other kind of input or output) if there is not a necessity to use it as CW/FSK output. This is the case in where not all signals (SPK, MIC and PTT) are available on a single connector, but where for example the receiver audio output signal is present on a separate socket. One should thus remove-cut the copper trace on SJ1 and take the signal with a wire from the left pad to the desired signal pin on the right row of the socket JP1 (see image below). This solution requires an extra wire, but avoids avoiding having to assemble a Y-cable between X2 and the transceiver.</p>
MIC	<p>Audio output to the microphone input (AC-coupled)</p> <p>This signal, according to the function of the transceiver model, may be available on the microphone connector, on the DATA or ACCessory connector. In the event that a DATA or ACCessory connector is available, it is recommended to use these in order to leave free the microphone socket, and consequently also the microphone itself.</p>
PTT	<p>Relay output for the PTT - (Max 100VDC / 0.5A)</p> <p>It is a contact that is normally open(NA) to the ground (GND)</p>
CAT	<p>power supply input for the CAT/CI-V interface</p>

TinyGate - User's manual and assembly instructions

PWR	Given the galvanic isolation of the interface CAT/CI-V it is necessary to supply it with external power (8-15VDC / 20mA). This power may for example be taken directly by some transceivers from the microphone connector, the DATA or ACCessory socket. In the case the CAT/CI-V interface of TinyGate is not used or in cases where galvanic isolation is not required, <u>it is not necessary</u> to get any power supply from the transceiver.
COR/ SQL	Input - Squelch Certain applications, (e.g. Echolink) support and use for the carrier detection and/or channel busy detection by this signal from the transceiver, but only some transceivers have this output available on a connector. On several transceivers of this sort it is necessary to get the SQUELCH signal from inside. The SJ6 and SJ13 bridges define whether this signal should be interpreted with a positive or negative logic.
CW/ FSK	Output - CW or else FSK (max. 50VDC / 50mA) It is a transistor output from a optocoupler. If necessary, you may connect this output with a 1.5kOhm-resistor to +5V (Pull-Up) through the SJ11 solder bridge.
GND	Ground (GND), connected to the shield of the RJ45 X2 socket and the RJ45 cable towards the transceiver. This ground is separated from the USB-ground of the circuit on the board and should be connected to the ground of the transceiver via the RJ45 patch cable or the CW / FSK cable.
GND	Ground (GND), connected to the shielding of the RJ45 X2 socket and the RJ45 cable towards the transceiver. This ground is separated from the USB-ground of the circuit on the board and should be connected to the ground of the transceiver via the RJ45 patch cable or the CW / FSK cable.




The RJ45 socket X2 is exclusively provided for the connection of a transceiver and not an Ethernet network port. Hence, a network device, such as a DSL router or similar device for example, must not be connected, otherwise it may be damaged by the TinyGate and/or the connected network device!

TinyGate - User's manual and assembly instructions

The RCA X1 (CW / FSK) socket may for example also be used as an audio input (or else as any other kind of input or output) if there is not the need to use it as a CW/FSK output. This is necessary in cases where not all signals (SPK, MIC and PTT) are available on a single connector, but where for example the receiver audio output signal is present on a separate socket. For this reason remove-cut the copper trace on SJ1 and bring the signal with a wire from the left pad to the desired signal pin on the right row of the socket JP1.


In the following example, the RCA X1 socket has been reconfigured as an audio input:



The transceiver cable


With the assembly kit there is a CAT5-FTP cable provided with a shielded RJ45 connector. If the cable in the kit should have two shielded RJ45 connectors and the transceiver has a different type of connector, it is then possible to remove one of these, cutting the cable near the connector. Certain transceivers have a RJ45 type microphone connector, in this case the cable with two RJ45 may become useful.

The transceiver should be connected to the RJ45 X2 socket via this cable, which should be set up on the open side (that which faces the transceiver) with a suitable connector for your transceiver itself. The necessary available signals have been described in the previous chapter "***Cable for connection to the transceiver***".



TinyGate - User's manual and assembly instructions

The shielded cable is made up of 4 twisted pairs of wires, which have the following colour code and assignment on the connector:



The shield is already attached to the ground (GND signal) in a fixed way from the board via the RJ45 X2 socket. As previously described, the signals present on the JP1 may be freely assigned to each pin of this connector. In any case, it is advised to connect at least the MIC and SPK signals on two different wire pairs, in order to thus obtain a better de-coupling between these signals.

This means that MIC and SPK should always be paired with a wire that is connected to ground (GND).

Examples of connection with transceivers

In the following tables there is an illustration of the assignment of the pins and wires for the cable towards some transceivers.





In any case errors are not excluded, and so, there should be considered as examples and only as guidelines for the cables assembly and not as guaranteeing the proper functioning with every specific transceiver.

In the assembly kit, there is also provided a piece of rigid and insulated copper wire which is suitable to build the jumpers to insert in JP1.


Elekraft KX3

The assignation of pins for the transceiver cable (X2 <-> PHONES + MIC):

X2 Pin	Jumpers on JP1 towards the signals 	Wire Colour	Pin on PHONES + MIC side panel view 
1	GND	 WHITE/Orange	3 (MIC)
2	MIC	 ORANGE/White	1 (MIC)
3	GND	 WHITE/Green	3 (PHONES)
4	PTT	 BLUE/White	2 (MIC)
5		 WHITE/Blue	
6	SPK	 GREEN/White	1 (PHONES)
7		 WHITE/Brown	
8		 BROWN/White	



Icom IC275, IC725, IC726, IC728, IC729, IC735, IC736, IC737, IC738, IC746PRO, IC756PROIII, IC761, IC765, IC775, IC781, IC820, IC821, IC910, IC970, IC7400, IC7600, IC7700, IC7800

The assignation of pins for the transceiver cable (X2 <->ACC1):

X2 Pin	Jumpers on JP1 towards the signals 	Wire Colour	Pin on ACC (1)  Rear panel view
1	GND	 WHITE/Orange	2
2	MIC	 ORANGE/White	4
3	GND	 WHITE/Green	2
4	PTT	 BLUE/White	3
5		 WHITE/Blue	
6	SPK	 GREEN/White	5
7	COR / SQL	 WHITE/Brown	6
8	PWR	 BROWN/White	7



TinyGate - User's manual and assembly instructions

JP1 - Jumpers example for the cable described above:



Yaesu FT100D, FT817, FT857, FT897



The assignation of pins for the transceiver cable (X2 <-> DATA transceiver):

X2 Pin	<p>Bridge on JP1 towards the signals</p> 	Wire Colour	<p>Pin on the DATA Rear panel view</p> 
1	GND	 WHITE/Orange	GND
2	MIC	 ORANGE/White	DATA IN
3	GND	 WHITE/Green	GND
4	PTT	 BLUE/White	PTT
5		 WHITE/Blue	
6	SPK	 GREEN/White	DATA OUT 1200
7	COR / SQL	 WHITE/Brown	SQL
8	PWR (only necessary for a galvanic isolated CAT interface)	 BROWN/White	

TinyGate - User's manual and assembly instructions

Option: CAT control via the CAT interface of the TinyGate:

Pinout of the CAT cable

<i>Pin CAT X3 input</i>	<i>Description</i>	<i>PIN on CAT / LINEAR</i>
		
1	TXD	RX D
2	RXD	TX D
3	GND (Ground of the transceiver)	GND

CAT / CI-V Interface mode solder bridge setting (SJ10):

solder bridge SJ10 on the position 2-3 (FIF232, IF232 mode)

We suggest to use the internal USB supply for the CAT interface to avoid to get the “+13,8V” from the CAT/LINEAR socket as external supply:

CAT / CI-V Interface Supply mode Jumper setting (SJ7 / SJ9):

<i>SJ7 Pos.</i>	<i>SJ9 Pos.</i>	<i>CAT Power supply port</i>
1-2	1-2	Internal (USB)

See also [CAT / CI-V power supply](#)

Yaesu FT1000 MARK-V, FT1000, FT990



The assignation of pins for the transceiver cable (X2 <-> PACKET Transceiver):

X2 Pin	Jumpers on JP1 towards the signals	Wire Colour	Pin on the PACKET  rear panel view
1	GND	 WHITE/Orange	2
2	MIC	 ORANGE/White	1
3	GND	 WHITE/Green	2
4	PTT	 BLUE/White	3
5		 WHITE/Blue	
6	SPK	 GREEN/White	4
7	COR / SQL	 WHITE/Brown	5
8	PWR (only necessary for a galvanic isolated CAT interface)	 BROWN/White	PIN4 (9V) on the socket DVS-2 (FT990) 

TinyGate - User's manual and assembly instructions

Option: CAT control via the CAT interface of the TinyGate:

Pinout of the CAT cable for FT990 and FT1000D

<i>Pin CAT X3 input</i>	<i>Description</i>	<i>PIN on the CAT socket</i>
		
1	TXD	3 SERIAL IN
2	RXD	2 SERIAL OUT
3	GND (Ground of the transceiver)	1 GND

CAT / CI-V Interface mode solder bridge setting (SJ10):

solder bridge SJ10 on the position 2-3 (FIF232, IF232 mode)

Yaesu FT840



The assignation of pins for the transceiver cable (X2 <-> Transceiver MIC and AF-OUT):

Pin X2	Jumpers on JP1 towards the signals	Wire colour of CAT5-FTP cable	Pin on the MIC (front panel view)	AF-OUT socket (rear panel view)
1	GND	WHITE/Orange	7	
2	MIC	ORANGE/White	8	
3	GND	WHITE/Green		Ground (ring)
4	PTT	BLUE/White	6	
5		WHITE/Blue		
6	SPK	GREEN/White		Center pin
7		WHITE/Brown		
8	PWR (only necessary for a galvanic isolated CAT interface)	BROWN/White		Center pin of „+13.5V“

TinyGate - User's manual and assembly instructions

Option: CAT control via the CAT interface of the TinyGate:

Pinout of the CAT cable for FT840

<i>Pin CAT X3 connector</i>	<i>Description</i>	<i>PIN on the CAT socket</i>	<i>Notes</i>
			
1	TXD	3 SERIAL IN	Add a 150 Ohm resistor between pin 3 and pin 1
2	RXD	2 SERIAL OUT	
3	GND (Ground of the transceiver)	1 GND	


CAT Serial baudrate: 4800 Bps

CAT / CI-V Interface mode solder bridge setting (SJ10):

solder bridge SJ10 on the position 2-3 (FIF232, IF232 mode)

Yaesu FT2000, FT920

The assignation of pins for the transceiver cable (X2 <-> PACKET Transceiver):




X2 Pin	Jumpers on JP1 towards the signals 	Wire Colour 	Pin on the PACKET  rear panel view
1	GND	 WHITE/Orange	2
2	MIC	 ORANGE/White	1
3	GND	 WHITE/Green	2
4	PTT	 BLUE/White	3
5		 WHITE/Blue	
6	SPK	 GREEN/White	4
7	COR / SQL	 WHITE/Brown	5
8		 BROWN/White	

Yaesu FT450, FT950, FT991

Icom IC2720H, IC2725E



Kenwood TS480, TM255, TM455, TM-G707, TM-V7, TM-D700x

**The assignation of pins for the transceiver cable
(X2 <-> transceiver RTTY/PKT/DATA):**

X2 Pin	Jumpers on JP1 towards the signals 	Wire Colour 	Pin on RTTY/PKT/DATA Rear panel view 
1	GND	 WHITE/Orange	2
2	MIC	 ORANGE/White	1
3	GND	 WHITE/Green	2
4	PTT	 BLUE/White	3
5		 WHITE/Blue	
6	SPK	 GREEN/White	5
7	COR / SQL	 WHITE/Brown	6
8		 BROWN/White	



Kenwood TS140, TS440(S), TS450S, TS570, TS590, TS680, TS690, TS850, TS870S, TS940(S), TS950S, TS990, TS2000(X)

The assignation of pins for the transceiver cable (X2 <-> ACC Transceiver):

X2 Pin	Jumpers on JP1 towards the signals 	Wire Colour 	Pin on ACC rear panel view 
1	GND	 WHITE/Orange	4
2	MIC	 ORANGE/White	11
3	GND	 WHITE/Green	8
4	PTT	 BLUE/White	9
5		 WHITE/Blue	
6	SPK	 GREEN/White	3
7	COR / SQL	 WHITE/Brown	5
8		 BROWN/White	



Kenwood R1000

The assignation of pins for the receiver cable (X2 <-> RECORD):

X2 Pin	Jumpers on JP1 towards the signals 	Wire Colour	Pin on RECORD front panel view 
1		 WHITE/Orange	
2		 ORANGE/White	
3	GND	 WHITE/Green	3
4		 BLUE/White	
5		 WHITE/Blue	
6	SPK	 GREEN/White	1
7		 WHITE/Brown	
8		 BROWN/White	



Kenwood TS50S

The assignation of pins for the transceiver cable (X2 <-> MIC Transceiver):

X2 Pin	Jumpers on JP1 towards the signals 	Wire Colour 	Pin on MIC front panel view 
1	GND	 WHITE/Orange	7
2	MIC	 ORANGE/White	1
3	GND	 WHITE/Green	8
4	PTT	 BLUE/White	2
5		 WHITE/Blue	
6	SPK	 GREEN/White	6
7		 WHITE/Brown	
8	PWR (only necessary for the CAT)	 BROWN/White	5

Icom IC703, IC706, IC718, IC7000, IC7100, IC7200, IC7300, IC7410, IC9100

The assignation of pins for the transceiver cable (X2 <-> ACC Transceiver):

X2 Pin	Jumpers on JP1 towards the signals 	Wire Colour 	Pin on ACC rear panel view 
1	GND	WHITE/Orange	2
2	MIC	ORANGE/White	11
3	GND	WHITE/Green	2
4	PTT	BLUE/White	3 + 7
5		WHITE/Blue	
6	SPK	GREEN/White	12
7	COR / SQL	WHITE/Brown	13
8	PWR (only necessary for the CAT)	BROWN/White	8

CAT / CI-V interface



CAT/CI-V connections

The TinyGate has a dedicated serial port for the control of a transceiver with a CAT/CI-V interface. The jack socket X3 allows a direct connection with a ICOM transceiver which support the CI-V, with the help of a simple audio cable with two 3.5mm-Jack plugs (stereo or mono).


The CAT/CI-V interface may be configured in two different modes:

1. CI-V mode

This mode is used by numerous ICOM transceivers and is essentially a TTL single wire serial port. **The TinyGate board is supplied already configured for the CI-V mode and for the external power supply of the CAT / CI-V Port.**

TinyGate - User's manual and assembly instructions


CI-V: Signals (socket "CAT" X3):

<i>Pin</i>	<i>Description</i>
	
1	CI-V RXD / TXD
2	
3	GND (Ground of the transceiver)

2. FIF-232, IF-232 mode

This mode provides two separate signals for RXD and TXD, and is essentially a serial port with TTL levels (0/5V).

FIF-232, IF-232 signals (socket "CAT" X3):

<i>Pin</i>	<i>Description</i>
	
1	TXD
2	RXD
3	GND (Ground of the transceiver)



TinyGate - User's manual and assembly instructions

To define the mode FIF232 (IF232), we have to set the SJ10 solder bridge as follows:

CAT / CI-V Mode Jumper setting (SJ10)

<i>Pos. SJ10</i>	<i>CAT Interface Mode</i>
1-2	CI-V (default)
2-3	FIF232, IF232, Elecraft

All of the solder bridges are on the bottom side of the board to simplify access to these. For the pre-set, subtle copper trace are used, which can be removed and opened with a cutter. In the following image there is an illustration of the position of SJ10 and SJ4:






CAT for ELECRAFT-Transceivers

An inverted logic level on the serial data lines is required to connect the CAT-interface to a Elecraft-Transceiver (models K2, K3, KX2, KX3). **This option is only available since the TinyGate board revision B** and can be set through the SJ14 solder bridge as follows:

Serial Data Line Mode jumper setting (SJ14)

Pos. SJ14	Inverted logic RXD and TXD
1-2	Not inverted (default)
2-3	Inverted (for Elecraft)



TinyGate - User's manual and assembly instructions

We have also to set the mode FIF232 (IF232), therefore it's necessary to set the SJ10 solder bridge to pos. 2-3 as follows:

CAT / CI-V Mode Jumper setting (SJ10)

<i>Pos. SJ10</i>	<i>CAT Interface Mode</i>
1-2	CI-V (default)
2-3	FIF232, IF232, Elecraft

The jack socket X3 allows a direct connection with a ELECRAFT transceiver which support the CAT, with the help of a simple audio cable with two 3.5mm-stereo Jack plugs.

CAT / CI-V power supply

The TinyGate has a very flexible interface, which allows it to be adapted to a wide range of transceivers.

To ensure the galvanic isolation of the CAT / CI-V port, an external power supply is necessary (8-15VDC). This may for example be directly take from the transceiver. See also [**Connection cable to the transceiver**](#)



If an external power supply isn't available directly from the transceiver, so it's possible to use the X1 (CW / FSK) socket to connect an external power supply. One should thus remove-cut the copper trace on SJ1 and add a wire jumper between pin 3 and pin 5 on the socket JP1.

The power supply to the CAT / CI-V port may be chosen as internal (from the USB) or external:

CAT / CI-V Interface Supply mode Jumper setting (SJ7 / SJ9)

<i>SJ7 Pos.</i>	<i>SJ9 Pos.</i>	<i>CAT Power supply port</i>
2-3	2-3	External (default)
1-2	1-2	Internal (USB)

TinyGate - User's manual and assembly instructions

1. External

The power supply for the CAT/CI-V port comes from the RJ45 X2 socket. This power is reduced inside the TinyGate with a linear voltage regulator (D2, T3) to about 5.1V. **The TinyGate board is pre-configured for the external power supply of the CAT / CI-V Port.**


2. Internal

The electrical supply to the CAT/CI-V port is internally taken from the USB port of the TinyGate.



CAUTION! Due to a common ground it is not possible to have a galvanic isolation between the TinyGate (the PC) and the CAT port of the transceiver if you use the internal supply!

The CAT/CI-V port and the SQL (COR) input use a common ground (defined with the SJ9 bridge), as a result, they should both be powered from the same supply (internal or external)!




CW / FSK control line setting (SJ12)

<i>Pos. SJ12</i>	<i>CW / FSK line of control (Mode)</i>
1-2	DTR (CW-Mode) (default)
2-3	TXD (FSK mode)


CW / FSK Pull-up resistor (SJ11)

<i>Pos. SJ11</i>	<i>CW / FSK pull-up resistor (1.5kΩ)</i>
open	disabled (by default)
close	enabled



CW / FSK Pull-up and SQL (COR) negative logic supply source (SJ8)

<i>Pos.</i> <i>SJ8</i>	Supply source for CW/FSK pull-up and negative logic SQL (COR)
1-2	Internal (USB)
2-3	external (default)



SQL (COR) Input

The SQL (COR) input is connected through an optocoupler to the CTS control line of the serial port (the same port used by the PTT / CW). The input of this optocoupler is an LED, which may be biased with a 2kΩ resistor with positive or negative logic (defined by SJ6 and SJ13). With SJ8 (see also Pull-Up resistor for the CW / FSK output) you can set the supply source (internal or external) in the case of negative logic. This supply voltage is also about 5.1V.

Power supply source for CW / FSK Pull-up resistor and negative logic SQL (COR) input (SJ8)


<i>SJ8</i> <i>Pos.</i>	<i>SJ9</i> <i>Pos.</i>	CW / FSK pull-up resistor / SQL (COR) negative logic entry
1-2	1-2	Internal (USB)
2-3	2-3	external (default)


TinyGate - User's manual and assembly instructions

<i>SJ6</i> <i>Pos.</i>	<i>SJ13</i> <i>Pos.</i>	SQL (COR) entry logic
1-2	2-3	positive (default)
2-3	1-2	negative



The CAT / CI-V port and the SQL (COR) input use a common ground (defined with the SJ9 bridge) as a result, they should both be supplied from the same supply source (internal or external)! See also ["CAT / CI-V Supply"](#)





Test – Initial operation

For the first use or test you may simply connect the TinyGate to your PC using the USB cable supplied with the kit. The operating systems should normally recognise TinyGate immediately, however it may occur that MS Windows requires the installation of the driver for the FTDI serial ports on the TinyGate. This driver may simply be downloaded from [the web page of the manufacturer](#) and installed. In the event that someone should have doubts or questions on the installation of the FTDI driver they may find a detailed description for numerous operating systems on the [site for the installation guide](#).



Important note! : The enclosure is connected to the ground of the USB Port and as a result to the ground of the connected PC!

When the TinyGate audio interface is recognised by the operating system, the green LED "PWR " should light up on the front panel:




Note: the green LED "PWR" on the front panel flashes when a software application accesses the TinyGate audio interface. **The "PWR" LED remains off until the operating system starts up and the relative audio drivers are loaded.**

In the following chapters, you will find a brief description with some screenshots about how to verify with Windows XP, Windows7 and Windows 10 whether the TinyGate has been correctly recognised.

Windows XP

If you connect the TinyGate for the first time, the following messages appear:




Once the operating system has installed the drivers, these messages shall disappear.

Now the device management:

A quick way of opening the device management is by going on


Start ->Control Panel -> System -> Hardware -> Device management

If the TinyGate is correctly recognised and all of the drivers have loaded, then following devices should result in the in the device manager:



TinyGate - User's manual and assembly instructions


TinyGate - User's manual and assembly instructions



It is useful to note that the progressive numbering of the two serial ports (COMx) depends on the PC and operating system, so it is possible that this should differ from PC to PC.

Windows 7

If you connect the TinyGate for the first time, the following messages appear:




Once the installation of the drivers is complete these windows may be closed.

Now the device management:

A fast way of opening the device manager is going on "Start" and inserting the text "Device management" into the search field and clicking on the result "Device management".

TinyGate - User's manual and assembly instructions


If the TinyGate is correctly recognised and all of the drivers have loaded, then this should result in the following devices in the device manager:



It is useful to note that the progressive numbering of the two serial ports (COMx) depends on the PC and operating system, so it is possible that this should differ from PC to PC.

Windows 10

If you connect the TinyGate for the first time, the following messages appear:




Once the installation of the drivers is complete these windows may be closed.

Now the device management:

A fast way of opening the device manager is going on "Start" and inserting the text "Device management" into the search field and clicking the on the result "Device management".

TinyGate - User's manual and assembly instructions

If the TinyGate is correctly recognised and all of the drivers have loaded, then this should result in the following devices in the device manager:




It is useful to note that the progressive numbering of the two serial ports (COMx) depends on the PC and operating system, so it is possible that this should differ from PC to PC.


TinyGate - User's manual and assembly instructions

Linux - Ubuntu

If you connect TinyGate to the PC, you will find the following CM108 audio devices on on the "sound setting panel":



TinyGate - User's manual and assembly instructions



From the line of command it is possible to verify the presence of the TinyGate USB devices using the command "lsusb":

```
Bus 002 Device 060: ID 0403: 6001 Technology Devices Future International Ltd FT232 serial (UART) IC
Bus 002 Device 059: ID 0d8c: 013C C-Media Electronics, Inc. CM108 Audio Controller
Bus 002 Device 060: ID 0403: 6001 Technology Devices Future International Ltd FT232 serial (UART) IC
Bus 002 Device 057: ID 05e3: 0608 Genesys Logic, Inc. Hub
```

In this case we see the following TinyGate USB devices :

the fourth is the USB hub
the first and the third are the serial ports
the second is the sound card

TinyGate - User's manual and assembly instructions

To check that the sound card has really been recognised by the system you may use the following command:

```
cat /proc/asound/cards
```

```
0 [HDMI]: HDA-Intel - Intel HDA HDMI
HDA Intel HDMI at 0xf0630000 irq 63
1 [PCH ]: HDA-Intel - HDA Intel PCH
CTRL + S HDA Intel PCH at 0xf0634000 irq 64
2 [Device ]: USB-Audio - USB PnP Sound Device
C-Media Electronics Inc. USB PnP Sound Device at usb-0000: 00:
14,0 à 1,2, full spe
29 [ThinkPadEC]: ThinkPad EC - ThinkPad Console Audio Control
ThinkPad Console Audio Control at EC reg 0x30, fw unknown
```

In this case, we see the device n ° 2 (C-Media Electronics Inc. USB PnP Sound Device) as the sound card of TinyGate.

To verify that the serial ports have really been seen by the system you may use the following command:

```
ls -alrt /dev/ttyUSB*
```


```
crw-rw---- 1 root dialout 188, 0 apr 30 22:07 /dev/ttyUSB0
crw-rw---- 1 root dialout 188, 1 apr 30 22:07 /dev/ttyUSB1
```

Caution! It is useful to note that the progressive numbering of the two serial ports (ttyUSBx) depends on the PC and operating system, so it is possible that this should differ from PC to PC.


TinyGate - User's manual and assembly instructions

MacOS -X

If the TinyGate is correctly recognised and all of the drivers have loaded, then this should result in the following devices in the System Report:




TinyGate - User's manual and assembly instructions



TinyGate - User's manual and assembly instructions



Important note! : You have to set the “Format” to 44100Hz for the TinyGate Sound device inside “Audio-MIDI-Setup”. This setting must be repeated one time on each USB port on your MAC. So if you change the USB port, the MAC will remember this setting above.



Examples of configurations for digital modes applications

Fundamentally TinyGate offers three available peripheral USBs:

- 2 serial ports
- 1 audio interface



As described in the previous chapter, the progressive numbering of the two serial ports (COMx) depends on the PC and operating system, so it is possible that this should differ from PC to PC.

Example: Let us suppose that, once the TinyGate is connected to a USB port of the PC, we have the following serial ports available:

USB Serial Port COM6

USB Serial Port COM7

Now we need to determine which of the two serial ports is for the CAT and which is for the PTT/CW. For this there are the following methods:

1. For those who have experience and familiarity with software applications in digital modes they may simply try which of the two ports is capable of activating the PTT. As a result the other serial port is the one for the CAT.

TinyGate - User's manual and assembly instructions


The two LEDs on the "TRANSCEIVER" X2 socket indicate when the CAT/CI-V serial port has transmitted or received data. If, for example, we try to transmit data on the CAT port without having connected any transceiver, we see a brief flashing of the yellow "CAT-TX" LED:



Ham Radio Deluxe V 5.24- Digital Master 780

As already explained, the TinyGate may be used with a wide range of software applications for digital modes. Below are illustrated configuration examples for some popular software in amateur radio, focused on the aspects linked to the parameters of the TinyGate hardware.

First of all, the sound card should be configured for use (audio input and output on TinyGate) under the menu "Program Options" -> "Soundcard":




TinyGate - User's manual and assembly instructions

Then, the serial port for the PTT should be chosen in the “PTT” sub-menu:



The relay of the PTT-Relay is controlled by default from the control line "RTS" of the serial port for the PTT / CW. See also „[PTT/CW/FSK outputs](#)“.



TinyGate - User's manual and assembly instructions

If someone want to work in CW with the Keyer input of the transceiver, they should choose the same serial port used for the PPT in the submenu "Modes + IDs", but using the "DTR" control line.




The CW output is preset to be controlled by the "DTR" command line of the serial port for the PTT. See also "[PTT/CW/ FSK Outputs](#)".

The screenshot shows the "Program Options" dialog box with the "CW" tab selected. The "Code Table" sub-tab is active, displaying information about CW variants. The "Modes + IDs" menu item in the left sidebar is circled in red. In the right-hand settings panel, the "Enable serial (COM) port keying" checkbox is also circled in red. Below this checkbox, the "Serial port" dropdown is set to "COM6", and the "Toggle pins" section has the "DTR" checkbox checked and the "RTS" checkbox unchecked. Other settings visible include "Use PTT" (unchecked), "Send" set to "space", and "1st extension" set to "0 ms".

TinyGate - User's manual and assembly instructions


The TinyGate integrated sound card has a preamplifier on the microphone input, that is activated via the software through the audio control panel of the operating system. Unfortunately, the term «AGC» for the preamplifier is not really self-explanatory.....:



In any case it is advisable to deactivate the preamplifier first and controlling the audio output level of the transceiver. Only if this was not sufficiently high despite the “RX” potentiometer being at maximum, then one may try and activate the preamplifier with “AGC”.

TinyGate - User's manual and assembly instructions


 Those who wish to listen the audio signal coming from the transceiver through the speakers of the predefined system or other audio outputs of the PC, may do so by activating the audio input of the TinyGate sound card as a source for playing:



TinyGate - User's manual and assembly instructions

In the "Soundcard" window, selecting "RX" at the bottom, the "Signal Level" vertical bar is displayed, with the actual audio signal level coming from the transceiver.

Selecting "TX" on the other hand, there is displayed the output sound level regulator of the TinyGate audio interface.



TinyGate - User's manual and assembly instructions



The output level may be regulated here via software, but may also be regulated with the "TX" potentiometer on the front panel. The software is not advised for use at an output level of 100%. On the other hand, it would be more indicated to put it at 50% and carry out the final regulation with the "TX" potentiometer. In any case, it should be noted that these two regulators are placed in series. This signifies for example, if you define the output level in the software as 0%, you will not manage to obtain any signal at the output even if the "TX" potentiometer is set to the maximum, either in a clockwise direction or the opposite.

When you start HamRadioDeluxe, you will be asked to select the transceiver model and the relative serial port for the CAT. In the following case, we have the CI-V/CAT-Port serial port of the TinyGate available as COM7:

Select a Preset or New definition and press 'Connect'

New Preset Serial Ports Help

Company: ICOM
Radio: IC-7400
COM Port: COM7
Speed: 19200
CI-V Add: 66

Flow control / Interface power
 CTS DTR RTS

Always connect to this radio when starting HRD
 Start HRD in Full Screen mode


Start: Digital Master 780
 Logbook
 Rotator
 Satellite Tracking

→ Connect

WSJT-X

Here, we show a few examples of the configuration for WSJT-X, focussing on the aspects linked to the parameters of the TinyGate hardware.


In the "Settings" of the "File", the audio interface should be chosen ("Audio IN" input and "Audio Out" output of the TinyGate audio interface), as well as the serial port used for the PTT "PTT Port" with the "PTT method" on RTS and the serial port for CAT, "CAT port":




FLDIGI & MacOS

Here, we show a few examples of the configuration for FLDIGI on MacOS, focussing on the aspects linked to the parameters of the TinyGate hardware.

In the "Audio" of the "Devices", the audio interface should be chosen ("Capture" input and "Playback" output of the TinyGate audio interface), as well as the serial port used for the PTT "RIG - Hardware PTT" with the "Use RTS" and the serial port for CAT, "RIG - RigCAT":



TinyGate - User's manual and assembly instructions



TinyGate - User's manual and assembly instructions

